



FORTINET

中文快速安裝手冊

FortiGate® 60F 系列





FORTINET®

FortiOS 6.0

11-620-2402x-20190715

Copyright© 2019 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, FortiCare® and FortiGuard®, and certain other marks are registered trademarks of Fortinet, Inc., in the U.S. and other jurisdictions, and other Fortinet names herein may also be registered and/or common law trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance and other metrics contained herein were attained in internal lab tests under ideal conditions, and actual performance and other results may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to certain expressly-identified performance metrics and, in such event, only the specific performance metrics expressly identified in such binding written contract shall be binding on Fortinet. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. In no event does Fortinet make any commitment related to future deliverables, features or development, and circumstances may change such that any forward-looking statements herein are not accurate. Fortinet disclaims in full any covenants, representations, and guarantees pursuant hereto, whether express or implied. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.





Product Registration

Thank you for purchasing a FortiGate. To access:

- Cloud Management ▪ FortiGuard Updates ▪ Firmware Upgrades
- Technical Support ▪ Warranty Coverage

Please register your FortiGate device:

Vous devez enregistrer le produit:

Debe registrar el producto:

登録のお願い:


請立即註冊:

<http://support.fortinet.com>






包裝內容



FortiGate® 60F Series



QuickStart Guide



Power Cable




12V Power Adapter



Wall Mount Hardware



Ethernet Cable




Wall Mount Kit





後面板




- 1** Power 12V DC, 100-240V AC 50/60Hz adapter
- 2** USB (USB A) USB 3.0 server port
- 3** Console (RJ-45) CLI management computer interface
- 4** WAN1 & WAN2 (RJ-45) 1 Gbps Ethernet interfaces
- 5** DMZ (RJ-45) 1 Gbps Ethernet interface
- 6** Ports A & B (RJ-45) 1 Gbps Ethernet interfaces (supports FortiLink)
- 7** Ports 1 to 5 (RJ-45) 1 Gbps Ethernet interfaces





前面板



1

2 4
3

5

1 LOGO

- ||| FortiGate
- Green: The device is on
- Off: The device is off

2 PWR

- Green: Power is on
- Off: Power is off

3 STATUS

- Green: Normal
- ⚡ Flashing Green: Booting up

4 HA

- Green: Operating in an HA cluster
- Amber: HA failover
- Off: Not in an HA cluster

5 PORT LINK/ACT

- Green: Connected
- ⚡ Flashing Green: Transmitting data
- Off: No link established

PORT SPEED


- Green: Connected at 1Gbps
- Amber: Connected at 100Mbps
- Off: Not connected or 10Mbps



安裝說明

此 FortiGate 包含壁掛安裝套件和連接線，可提供桌面安裝、壁掛安裝和機架安裝套件。

基本接線方式




1. 用包裝內附上的電源線插上電源插座。
2. 用包裝內提供的網路線連接 WAN port 到 internet 。

備註：建議將您的 FortiGate 接上不斷電系統以免突然斷電。




壁掛選項


1. 使用壁掛支架在牆上畫上鑽孔位置。




2. 鑽孔以放入膨脹釘。
3. 插入膨脹釘，鎖入螺絲，讓螺絲突出2mm。



4. 將壁掛架鎖上 FortiGate。



5. 將 FortiGate 對準螺絲安裝到牆面上。




6. 將電源線插上後面板的電源插頭，然後另一端插到電源插座上。





桌面安裝選項


1. 將 FortiGate 在平穩乾淨的表面上。
2. 確保在周邊至少有1.5英吋的散熱空間。



3. 將電源線插上後面板的電源插頭，然後另一端插到電源插座上

機架安裝選項

提供各種標準和訂製機架和滑軌安裝附件，包括60F機架安裝托盤套件，SP-RACKTRAY-02。



SP-RACKTRAY-02

訂購：聯繫 Fortinet 訂購支架，滑軌套件、機架安裝套件和其他配件，如 Console 線材。



軟體設定選項

在本地或雲端設定您的設備，選擇以下選項以完成設置，然後配置您的設備。



Local Setup

Web-Based Manager (GUI)

An **easy-to-use Web GUI**, compatible with most web browsers. To minimize scrolling, the screen resolution should be at least 1280 x 1024 pixels.



Cloud Setup

FortiGate Cloud

FortiGate Cloud is a **cloud-based infrastructure management solution** and log retention service. It provides **centralized reporting, traffic analysis, configuration management, and log retention** without the need for additional hardware and software.



Smartphone Setup

FortiExplorer

FortiExplorer for iOS is a **user-friendly iOS application** that helps you **configure, manage, and monitor** appliances. FortiExplorer rapidly provisions, deploys, and monitors **Security Fabric components** such as **FortiGate, FortiWiFi, and FortiAP** devices.




Local Setup

Command Line Interface (CLI)

An alternate configuration tool from the web-based manager that uses a **terminal emulation** application to **type commands** or upload batches of commands from a text file or **configuration script**. Requires a console cable (available for purchase).



GUI



1. 使用 **Ethernet Cable** 連接 **Port 1** 到 **Management Computer**。
2. 啟用 DHCP 或是設定管理電腦的 IP 和 subnet 為：

Static IP Address: **192.168.1.1**
 Subnet Mask: **255.255.255.0**

Setup

3. 使用網頁瀏覽器連上 **192.168.1.99**。
4. 使用 **username admin** 和 **no password** 登入。
5. 當提示要求註冊，輸入你的 **FortinetOne** 憑據。

FortiCare Registration Required

Serial Number *FG800D3915800295*

Action

Email

Password

Forgot your password?

Country

Reseller


6. 然後 **FortiCare Support Status** 會變更為 **Registered**。

Contract	Status
FortiCare Support	✔ Registered




FortiGateCloud

1. 使用你的 FortinetOne 憑據登入 forticloud.com。



The image shows the Fortinet One login page. At the top is the Fortinet One logo with the tagline 'Unified Cloud Services Login'. Below the logo are two input fields: 'Account ID/Email' and a password field with six asterisks. A blue 'LOGIN' button is positioned below the password field. Underneath the login button are two links: 'Forgot account ID/Email?' and 'Forgot password?'. At the bottom of the login area are two buttons: a red 'REGISTER' button and a grey 'HELP' button. Below these buttons is a link that says 'Learn more about FortinetOne'.

2. 點選 **Add FortiGate** 然後輸入 **Cloud Key** (在你的 FortiGate 裝置上的貼紙)




3. 然後你可以在雲端管理你的 FortiGate 裝置。

備註：你需要在 support.fortinet.com 註冊以取得 FortinetOne 帳號。




FortiExplorer



FortiExplorer App


1. 下載並執行 **FortiExplorer iOS App**
2. 點取 **Add Device** 然後選擇 **FortiGate Cloud**
3. 輸入你的 **FortinetOne** 憑據，然後掃描 **Cloud Key** 的 QR code。
4. 然後你可以在你的 **iOS** 設備上設定你的 **FortiGate** 裝置。

Setup





CLI



1. 使用 console cable 連接 Console Port 到 Management Computer。
2. 在 Management Computer 上開啟終端機軟體，然後選擇 COM Port，使用以下的設定：

Baud rate: 9600
Data bits: 8
Parity: None
Stop bits: 1
Flow control: None

3. 使用 username admin 及 no password。
4. 你可以開始設定你的裝置。

```
FortiGate # ?
config      Configure object.
get         Get dynamic and system information.
show        Show configuration.
diagnose    Diagnose facility.
execute     Execute static commands.
exit        Exit the CLI.

FortiGate # config ?
alertemail  Alert email configuration.
antivirus   AntiVirus configuration.
application Application control configuration.
client-reputation Client reputation tracking configuration
dlp         DLP configuration.
endpoint-control Endpoint control configuration.
firewall    Firewall configuration.
ftp-proxy   FTP proxy configuration.
gui         GUI configuration.
icap        ICAP client configuration.
imp2p       IM & P2P policy configuration.
ips         IPS configuration.
--More--
```

備註：輸入 ? 以取得指令列表，輸入一個指令加上 ?，例如 config ? 以列出設定選項，有關更多的選項，請訪問 support.fortinet.com。





Resources

Refer to the following resources to continue your FortiGate setup.

FortiGate Documentation Library

Up-to-date hardware and software guides

<https://docs.fortinet.com/fortigate>

Fortinet Customer Service & Support

Access knowledge bases, resource libraries and contact support

<https://support.fortinet.com/>

Fortinet Online Help

View Firmware, CLI and product-specific documentation

<https://help.fortinet.com/>

Fortinet Video Tutorials

FortiOS Tips, Web GUI tutorials, SD-WAN tricks and more

<http://video.fortinet.com>

FortiGuard Labs

Discover FortiGuard's Zero-Day Research, Weekly Threat Briefs and Threat Lookups

<https://fortiguard.com/>

Setup



Cautions and Warnings

Environmental specifications

Ambient operating temperature: 0°C to 40°C

Refer to specific Product Model Data Sheet for Environmental Specifications (Operating Temperature, Storage Temperature, Humidity, and Altitude)

Référez à la Fiche Technique de ce produit pour les caractéristiques environnementales (Température de fonctionnement, température de stockage, humidité et l'altitude)

Safety

Battery – Risk of explosion if the battery is replaced by an incorrect type. Do not dispose of batteries in a fire. They may explode. Dispose of used batteries according to your local regulations. IMPORTANT: Switzerland: Annex 4.10 of SR814.013 applies to batteries.

Batterie – Risque d'explosion si la batterie est remplacée par un type incorrect. Ne jetez pas les batteries au feu. Ils peuvent exploser. Jetez les piles usagées conformément aux réglementations locales. IMPORTANT: Suisse: l'annexe 4.10 de SR814.013 s'appliquent aux batteries.

警告
本電池如果更換不正確會有爆炸的危險
請依製造商說明書處理用過之電池

CAUTION:

There is a danger of explosion if a battery is incorrect replaced. Replace only with the same or equivalent type.

Dispose batteries of according to the manufacturer's instructions.

Disposing a battery into fire, a hot oven, mechanically crushing, or cutting it can result in an explosion.

Leaving a battery in an extremely hot environment can result in leakage of flammable liquid, gas, or an explosion.

If a battery is subjected to extremely low air pressure, it may result in leakage of flammable liquid, gas, or an explosion.

WARNING:

Lithium-Batterie Achtung: Explosionsgefahr bei fehlerhafter Batteriewechsel. Ersetzen Sie nur den gleichen oder gleichwertigen Typ. Batterien gemäß den Anweisungen des Herstellers entsorgen.

Beseitigung einer BATTERIE in Feuer oder einen heißen Ofen oder mechanisches Zerkleinern oder Schneiden einer BATTERIE, die zu einer EXPLOSION führen kann.

Verlassen einer BATTERIE in einer extrem hohen Umgebungstemperatur, die zu einer EXPLOSION oder zum Austreten von brennbarer Flüssigkeit oder Gas führen kann.

Eine BATTERIE, die einem extrem niedrigen Luftdruck ausgesetzt ist, der zu einer EXPLOSION oder zum Austreten von brennbarer Flüssigkeit oder Gas führen kann.

This product is intended to be supplied by a Listed Direct Plug-In Power Unit marked LPS or Class 2 and rated 12 Vdc, 3 A.

Le produit doit être alimenté par un bloc d'alimentation à courant continu homologué UL de 12 Vdc, 3 A nominal marqué LPS ou Class 2.

Regulatory Notices

Federal Communication Commission (FCC) – USA

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received; including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Industry Canada Equipment Standard for Digital Equipment (ICES) – Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

European Conformity (CE) - EU

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.



Voluntary Control Council for Interference (VCCI) – Japan

この装置は、クラスB機器です。この装置は、住宅環境で使用することを目的としています。この装置が、受信機を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

V C C I – B

Product Safety Electrical Appliance & Material (PSE) – Japan

日本では電気用品安全法(PSE)の規定により、同梱している電源コードは、専用の専用電源コードとして利用し、他の製品に使用しないでください。

Bureau of Standards Metrology and Inspection (BSMI) – Taiwan

The presence conditions of the restricted substance (BSMI RoHS table) are available at the link below:

限用物質含有情況表 (RoHS Table) 請到以下 網址下載 :

<https://www.forinet.com/bsmi>

英屬蓋曼群島商法特種股份有限公司台灣分公司
地址：台北市內湖區行復路176號2樓
電話：(02)27961666



FORTINET®

[Fortinet.com](https://www.fortinet.com)

